



Instructions for applying thermal transfer stickers to fabric.

The fabric must be cotton or mixed and withstand an ironing temperature of 140 degrees. This is usually indicated on the label with an iron symbol with two dots.

1. Clean the fabric from dust with a sticky roller and iron it.
2. Adjust the iron to 135-140 degrees. Test the fabric with an iron in an invisible place.
3. Place the sticker in the desired location with the glossy surface facing up.
4. Press the sticker with an iron for 12-15 seconds. if necessary, lift and move the iron to another part of the sticker.
5. Wait until the sticker film cools down a little and carefully remove it.
6. Place the film back onto the picture and rub the entire picture in a circular motion for 10-15 seconds.
7. If the texture of the fabric becomes slightly visible in the picture, then you have pasted it well. If not, repeat step 6.